



TECHNICAL HANDOUT

CHANGING THE DATE AND TIME ON THE

Interconnect 200

FROM THE MAIN CONSOLE (Switchboard)

1. Press **F1** Main menu
2. Press **F6** System configuration
3. Press **F4** System configuration
4. Press **F9**
5. Enter password **U U P F C L**
6. Arrow down to the **Time** field
7. Change time as required
8. Arrow down off of the time field
9. If you don't want to change the date skip to 13
10. Arrow down to the **Date** field
11. Change the Date as required
12. Arrow down off the date field
13. Press **F1** followed by your normal choice of screen

If you have any problems with the above, please call our

Support Department on 08450 34 55 66