



TECHNICAL HANDOUT

CHANGING THE DATE AND TIME ON THE Panasonic SDBS

From a display phone on either extension 20 or 21

TO SET THE TIME

1. Leave the handset on hook
2. Press **ON/OFF**
3. Press **RECALL**
4. Dial **#4**
5. Enter hour (**00 to 23**)
6. Enter minute (**00 to 59**)
7. Press **ON/OFF**

TO SET THE DATE

1. Leave the handset on hook
2. Press **ON/OFF**
3. Press **RECALL**
4. Dial **#3**
5. Enter day (**01 to 31**)
6. Enter month (**01 to 12**)
7. Enter year (**00 to 99**)
8. Press **ON/OFF**

If you have any problems with the above, please call our

Support Department on 08450 34 55 66