



TECHNICAL HANDOUT

CHANGING THE DATE AND TIME ON THE

Samsung SKP 308

From a LCD display phone

1. Press the **#** key
2. In the display of the phone programming will be displayed
3. Dial **04**
4. "Mmc disabled" or "enabled" is displayed
5. Dial the four digit password (**4 3 2 1**)

6. Dial **1** to enable programming
7. Press the **#** key **twice**
8. Dial **55**
9. The display shows YY MM DD W HH MM
10. Enter the new date successively

11. **YY** last 2 digits of year
12. **MM** month of year (01-12)
13. **DD** date (01-31)
14. **W** day: **1**=Mon **2**=Tue **3**=Wed **4**=Thu **5**=Fri **6**=Sat **7**=Sun
15. **HH** hour (24 hour clock)

16. **MM** minutes (00-60)
17. Press **#** key

**If you have any problems with the above, please call our
Support Department on 08450 34 55 66**